BEST ACCESS DOORS
Quality Access Doors- **FAST!**

INSTALLATION GUIDE

TELEPHONE:
1-800-483-0823
FAX:
1-888-828-6021

228 PARK AVE. S. #76520
NEW YORK, NY, 10003

WEBSITE:
www.BestAccessDoors.com
E-MAIL:
info@bestaccessdoors.com

SKU: BA-PFN — FIRE RATED UNINSULATED ACCESS DOOR

■ WALL INSTALLATION PROCEDURE

1. Opening dimensions should be 1/4" larger than catalogue size of door; i.e., for a 12" x 12" door, opening should be 12 1/4" x 12 1/4" once drywall boards are installed.
2. Place door in position in the opening and mark location of attachments on studding, using holes in latch and hinge sides of door frame as marking guides.
3. Remove door, and drill 5/32" holes through studding at points marked for attachment holes.
4. Place door in position and attach with #10 drywall screws.
5. Check door panel for freedom of movement. If it binds, shim to remove any racking of frame at attachments to studding.
6. In order to ensure that the door is self-closing it must be automatically latch and lock when released from at least 60 degrees of openness.
7. Open the spring kit provided in the box and install one single spring between frame (hinge side) and the hook on the back of the door panel
8. When mounting access panels with galvanized beaded frame (instead of 1" steel trim), once beaded frame is fastened use drywall cement and tape drywall to cover and conceal the flange.

Masonry

Latch release

Spring

Steel or wood stud

Slam latch

1"

Gypse

Piano hinge

1" Flange

Authorities Having Jurisdiction (AHJ) should be consulted in all cases as to the particular requirements and use of fire rated access doors.

2 1/2"

* Chip out masonry wall to clear latch cover