

SKU: BA-LT-4000

UNIVERSAL FLUSH INSTALLATION AND MAINTENANCE INSTRUCTIONS

■ INSTALLATION INSTRUCTIONS

1. Slide the RETURN FLANGE of Access Door into opening.
2. Open panel to access .28" diameter mounting holes in RETURN FLANGE.
3. Screw through these holes into joist system or whatever frame is available. Where a frame is unavailable on at least (2) two opposite sides of the Access Panel, unit will need to be "framed out." (Chocks of wood are used in place of normal joists).
4. After screws are in place close unit and secure all screwdriver operated cams shut.
5. Paint the unit if necessary. (Mill Finish, does not require painting).

